


Classic Palmiers

Baking Instruction Sheet



1. Remove frozen Palmiers from box and break apart using a knife or some other cutting tool.



1. Place Palmiers on pan as shown. Be sure they have enough room to completely spread apart. Preheat oven to 375 degrees.



3. Bake frozen Palmiers at 375 degrees in a convection oven for around 16 to 20 minutes. Palmiers should be puffed up and light golden brown in color when done.